



IMPORTANT NOTICE

96XX CABINET INSTALLATION PROCEDURE



THE 96XX CABINET INSTALLATION PROCEDURE HAS CHANGED!

PLEASE BE SURE TO FOLLOW THE INSTRUCTIONS IN THE **96XX CASH DISPENSER CABINET INSTALLATION GUIDE (VERSION 2.0)** TO ENSURE YOUR UNIT IS INSTALLED CORRECTLY! SEE THE LIST BELOW FOR A SUMMARY OF IMPORTANT CHANGES TO THE INSTALLATION PROCEDURE.

IMPORTANT CHANGES HAVE OCCURRED TO THE FOLLOWING ANCHOR-BOLT DRILLING AND CABI- NET MOUNTING REQUIREMENTS:

1. ANCHOR-BOLT TYPE.
2. ANCHOR-BOLT HOLE DEPTH.
3. ANCHOR-BOLT TORQUE SPECIFICATION.

IN ADDITION, THE USE OF LEVELING FEET ON BUSINESS HOURS SERVICE UNITS IS NOW OPTIONAL (THE LEVELING FEET ARE PROVIDED IN THE ACCESSORIES BOX).



IMPORTANT NOTICE

96XX CABINET INSTALLATION PROCEDURE



THE 96XX CABINET INSTALLATION PROCEDURE HAS CHANGED!

PLEASE BE SURE TO FOLLOW THE INSTRUCTIONS IN THE **96XX CASH DISPENSER CABINET INSTALLATION GUIDE (VERSION 2.0)** TO ENSURE YOUR UNIT IS INSTALLED CORRECTLY! SEE THE LIST BELOW FOR A SUMMARY OF IMPORTANT CHANGES TO THE INSTALLATION PROCEDURE.

IMPORTANT CHANGES HAVE OCCURRED TO THE FOLLOWING ANCHOR-BOLT DRILLING AND CABI- NET MOUNTING REQUIREMENTS:

1. ANCHOR-BOLT TYPE.
2. ANCHOR-BOLT HOLE DEPTH.
3. ANCHOR-BOLT TORQUE SPECIFICATION.

IN ADDITION, THE USE OF LEVELING FEET ON BUSINESS HOURS SERVICE UNITS IS NOW OPTIONAL (THE LEVELING FEET ARE PROVIDED IN THE ACCESSORIES BOX).