SUBJECT:	TECHNICAL BULLETIN: 17-08
X3 UPGRADE KITS FOR RL2/RL5/RT2/FT5	DATE: AUGUST 04, 2017

Available to all authorized Triton distributors and third party service providers.

RELEASE OF X3 UPGRADE KITS FOR RL2/RL5/RT2/FT5 FOR US, UK, CANADIAN, AND AUSTRALIAN MARKETS.

Triton announces the release of X3 main boards for RL2, RL5, RT2 and FT5 units. The new main boards and applicable software will be sent out with all units beginning in August 2017. The X3 main boards boast faster processing time for CPU-intensive operations, such as boot up, and viewing journals or other reports.

	X2	X3
Operating System	Windows CE6	Windows Compact 7
Processor	Cirrus EP9307	Freescale i.MX287
Memory (RAM)	128 MB	128 MB
Flash (Storage)	128 MB	128 MB
Processor Speed	200 MHz	454 MHz

See page 2 for upgrade kit information.

The following assemblies will be available via www.atmgurus.com for X2-toX3 field upgrade in August 2017.

Country	Model	Display	Part Number	Description
Australia	RL2 RL5/FT5/RT2	8" 10.4"	09214-21004	X3 module with base board and housing assembly
Canada	RL2	5.7"	09212-32002	X3 module with base board and housing assembly
Canada	RL2 RL5/FT5/RT2	8" 10.4"	09212-21002	X3 module with base board and housing assembly
UK	RL2 RL5/FT5/RT2	8" 10.4"	09216-21006	X3 module with base board and housing assembly
US	RL2	5.7"	09211-32001	X3 module with base board and housing assembly
US	RL2 RL5/FT5/RT2	8" 10.4"	09211-21001	X3 module with base board and housing assembly

The following kits are available via **www.atmgurus.com** for Xscale-to-X3 field upgrades. Item marked with a single asterisk (*) requires the X3 main board to be purchased separately, while items marked with a double asterisk (**) require the X3 main board and power supply to be purchased separately.

A dual power supply is required for ATMs running a TDM, SDD, or NMD 50 dispenser. Triton strongly recommends upgrading the power supply at this time, if necessary.

Country	Model	Display	Part Number	Description
All	FT5	10.4"	06200-00288	*FT Xscale-to-X3 upgrade kit without main board
All	RL5	10.4"	06200-00287	**RL Xscale-to-X3 upgrade kit without main board or power supply
All	RT2	10.4"	06200-00289	**RT Xscale-to-X3 upgrade kit without main board or power supply

06200-00287 shown above. **X3 main board and power supply
sold separately.

If you have questions regarding this Technical Bulletin, please contact Technical Support at 1-228-575-3100, option 4 or toll free in the U.S. / Canada 1-800-259-6672, option 4. Visit www.tritonatm.com for additional information. For all ATM parts, repair, and training needs, visit www.atmgurus.com.