

RL/FT5000 MAIN MENU MANAGEMENT FUNCTIONS

1 TERMINAL CLOSE FUNCTIONS 1. SCHEDULE CLOSE 2. SEND TERMINAL TOTALS: ON / OFF 3. TRIAL CLOSE 4. DAY CLOSE 5. TRIAL CASSETTE CLOSE 1. CASSETTE A 2. CASSETTE B 3. CASSETTE C 4. CASSETTE D 6. CASSETTE CLOSE 1. CASSETTE A 2. CASSETTE B 3. CASSETTE C 4. CASSETTE D			4 PASSWORD MAINTENANCE 1. CHANGE USER PASSWORD 2. CHANGE USER NAME 3. MODIFY USER ACCESS 4. ADD USER 5. REMOVE USER 6. TERMINAL USERS 7. USER ACCESS REPORT			6 TERMINAL CONFIGURATION 1. GENERAL PARAMETERS 1. TERMINAL NUMBER 2. ZIP CODE 3. RESET SEQUENCE NUMBER 4. DEFAULT LANGUAGE 5. DEFAULT TRANSACTION TYPE 6. DEFAULT ACCOUNT TYPE 7. OUT OF SERVICE ON LOW PAPER 8. OUT OF SERVICE ON PRINT ERROR 9. STATUS MONITORING 0. HEARTBEAT MESSAGE F1. DELAY PERIOD 2. COUPONS 1. COUPON 2. PROMPT 3. MINIMUM LEVEL 4. MAXIMUM LEVEL 5. RANDOM 6. AWARD BASED ON ISO PROP 7. MESSAGE 8. LAYOUT 9. GRAPHIC 0. PRINT F1. CASSETTE F2. COUNT 3. TERMINAL MESSAGES 1. WELCOME MESSAGE 2. STORE MESSAGE 3. MARKETING MESSAGE 4. EXIT MESSAGE 5. TERMINAL OWNER MESSAGE 6. SURCHARGE OWNER MESSAGE 7. NEWS TICKER MESSAGE 4. CASSETTE SETUP 1. MAXIMUM CASH 2. MAXIMUM NON-CASH 3. EXTENDED AMOUNTS 4. FAST CASH 1 5. FAST CASH 2 6. FAST CASH 3 7. FAST CASH 4 8.. FAST CASH 5 9. CASSETTE PARAMETERS 5. ISO / SURCHARGE PROPERTIES 1. ENABLE SURCHARGE 2. AMOUNT 3. PERCENT 4. USE WHAT IS LESSER/GREATER 5. ALLOW ISOs LISTED 6. ADD NEW ISO 7. DELETE ISO 8. EDIT ISO 6. COMMUNICATION 1. PRIMARY NUMBER 2. BACKUP NUMBER 3. PREDIAL 4. COMMUNICATION HEADER 5. COMMUNICATION HEADER # 6. USE 12-BYTE SEQUENCE # 7. ENABLE MAC-ing 8. COMMUNICATION PROTOCOL 9. COMMUNICATION MESSAGE 0. NUA NUMBER (DATAPAK USE) F1. ENABLE PERSISTENT REVERSALS F2. REVERSAL ATTEMPTS F3. ENABLE REVERSALS FOR PROTOCOL ERRORS 7. ADS / GRAPHICS 1. ADD NEW 2. DELETE 3. MOVE UP 4. MOVE DOWN 5. EDIT 8. OPTIONAL SCREENS (ENABLE / DISABLE FUNCTIONS) 1. ACCOUNT / TRANSACTION 2. LANGUAGE SELECTION 3. RECEIPT OPTION 4. SURCHARGE OPTION 9. OPTIONAL SCREEN BUTTONS (ENABLE / DISABLE FUNCTIONS) 1. ACCOUNT / TRANSACTION TYPE 2. FAST CASH AMOUNTS 3. PURCHASE SELECTIONS 0. TRITON CONNECT 1. PRIMARY PHONE # 2. BACKUP PHONE # 3. ALARM MONITOR PRIMARY # 4. ALARM MONITOR BACKUP # 5. MAX RETRIES 6. REDIAL DELAY 7. ENABLE TRITON CONNECT 8. ENABLE CALL BACK 9. ENABLE SCHEDULED JOURNAL CALLS 0. TIME F1. ENABLE CALL AT # OF JOURNAL RECORDS F2. ENABLE CALL AT LOW CASH F3. ENTER NEW ACCESS CODE		
2 DIAGNOSTICS 1. TERMINAL STATUS 1. CURRENT TERMINAL ERROR 2. TERMINAL ERROR HISTORY 3. RESET TERMINAL ERROR 4. CONFIGURATION SUMMARY 5. RESTORE DEFAULT PARAMETERS 6. SAVE PARAMETERS TO EXTERNALSTORAGE 7. RESTORE PARAMETERS FROM EXT. STORAGE 2. TRANSACTION TOTALS 3. SYSTEM DIAGNOSTICS 4. DISPENSER 1. CASH DISPENSER STATUS 2. PURGE 3. TEST DISPENSE 4. INJECT NEW CASSETTE ID 5. FORCE UNLOCK CASSETTE 6. DISPENSER TOTALS 7. RESET DISPENSER 8. CASSETTE PARAMETERS 5. CARD READER 1. CARD READER STATUS 2. CARD READER TOTALS 3. SCANCARD 6. PRINTER 1. DEVICE STATUS 2. RESET / TEST 3. CONFIGURE PRINTER 7. MODEM / ETHERNET 1. DEVICE STATUS 2. TEST 3. MODEM TOTALS 4. CONFIGURE MODEM 5. TRITON CONNECT SETTINGS 6. CONFIGURE ETHERNET SETTINGS 8. KEYPAD 1. DEVICE STATUS 2. TEST 9. GENERAL I / O DIAGNOSTICS 1. LED INDICATORS 2. AUDIO OUTPUT 3. HEADPHONE INTERRUPTS			5 SYSTEM PARAMETERS 1. DATE AND TIME 1. SET DATE 2. SET TIME 3. ADVANCED SETTINGS 2. REGIONAL SETTINGS 1. REGION 2. NUMBERS 3. CURRENCY 4. TIME 5. DATE 3. VOLUME CONTROLS 4. SHUT DOWN THE TERMINAL 5. RESTART THE TERMINAL 6. SELECT SCREEN FILE 7. SOFTWARE UPDATE 8. STATISTICS 9. SCHEDULE REBOOT 1. ENABLE / DISABLE SCHEDULE 2. TIME SET / DAY SELECT FEATURE			7 KEY MANAGEMENT 1. ENTER MAC MASTER KEYS 2. ENTER PIN MASTER KEYS 3. INJECT MASTER KEYS 4. DOWNLOAD WORKING KEYS 5. CHECK DIGITS		
3 ELECTRONIC JOURNAL 1. DISPLAY UNAUDITED RECORDS 2. DISPLAY LAST X 3. DISPLAY SELECTED RECORDS 1. ALL / UNAUDITED / AUDITED 2. RECORD TYPE 3. ALL / SELECTED DATES 4. START DATE 5. END DATE 6. FIELD 7. CONTAINS 4. CLEAR JOURNAL 5. ARCHIVE/DELETE JOURNAL 6. VIEW JOURNAL ARCHIVE 7. JOURNAL PROPERTIES 8. AUTO ARCHIVE			8 TERMINAL STATUS 1. CURRENT TERMINAL ERROR 2. TERMINAL ERROR HISTORY 3. RESET TERMINAL ERROR 4. CONFIGURATION SUMMARY 5. RESTORE DEFAULT PARAMETERS 6. SAVE PARAMETERS TO EXTERNAL STORAGE 7. RESTORE PARAMETERS FROM EXTERNAL STORAGE			9 LANGUAGE: ENGLISH / FRANCAIS / ESPANOL		
0 MORE OPTIONS 1. PREPAID PHONE 1. TERMINAL ID 2. PRIMARY PHONE # 3. BACKUP PHONE # 4. USE PHONE # FOR DAY CLOSE 5. (5 - 0, F1) LONG DISTANCE FAST CASH AMOUNTS 2. CHECK CASHING 1. TERMINAL ID 2. PRIMARY PHONE # 3. BACKUP PHONE # 4. USE PHONE # FOR DAY CLOSE 5. MAXIMUM AMOUNT 3. MONEY TRANSFER 1. TERMINAL ID 2. PRIMARY PHONE # 3. BACKUP PHONE # 4. CUSTOMER HELP # 5. USE PHONE # FOR DAY CLOSE 6. MULTIPLE AMOUNT 7. MAXIMUM AMOUNT 8. RECEIVE PAN #								