

TECHNICAL TIP

SUBJECT:
NMD-100 QUICK REFERENCE GUIDE

TECHNICAL TIP: 23-01A
DATE: FEBRUARY 27, 2023

This Technical Tip adds additional information to Technical Tip 23-01.

List of information:

- NMD component names and locations
- NMD Status report information in non-error state
- Aid for BCU alignment aid
- Feed Channel Status: Exit sensor obstruction, Feed Channel Jam clearance
- Component identifications, Stacker Presenter orientation
- CMC200 and NFC200 connector port identification
- Note Qualifier Exterior and Interior components
- Note Diverter tabs and jam clearance
- Different stages of note conditions and proper quantity of notes in cassettes without counting notes
- Power supply ports for NFC and CMC circuit boards

This Technical Tip references the NMD-100 Quick Reference Guide at Triton's website under Products > Triton's ATMs > ARGO FT > Manuals and Doc.

If you have questions regarding this Technical Tip, please contact Technical Support at 1-228-575-3100, option 3 or toll free in the U.S. / Canada 1-866-787-4866, option 3. Visit www.triton.com for additional information. For all ATM parts, repair, and training needs, visit www.atmgurus.com.