

## TECHNICAL¶ BULLETIN

**TECHNICAL BULLETIN: 13-14 Update** 

**DATE:** July 8, 2013

**SUBJECT:** Adjusting the SDD Dispenser Contra Roller Setting (UPDATE)

The older SDD model 8510 distance on the contra roller is different than current production SDD. The calibration setting is different. Therefore, the 19.65 mm adjustment may be too tight. At this time do not use the SDD Canadian Polymer Tool, part #03011-02150 on Model 8510 Triton is testing the optimal setting for the 8510 model of SDD. Triton will provide an update when available.

